

**tissin**

**Smart Position Transmitter**

**TS500 Series**

**Instruction manual**



**Tissin Co.Ltd.**

Ver. PM-TS500EN\_07/2025

## Table of contents

<b>1</b>	<b>Introduction</b>	3
1.1	General information for the user	3
1.2	Limited warranty and disclaimer	3
1.3	Requirements for safety	4
<b>2</b>	<b>Product Description</b>	5
2.1	Function	5
2.2	Features	5
2.3	Label	5
2.4	Product code	6
2.5	Specification	6
2.6	Exploded view	7
2.7	Principle of operation	10
2.8	Product Dimension	11
<b>3</b>	<b>Installation</b>	13
3.1	Before installation	13
3.2	Effective angle of operation	13
3.3	Linear type	14
3.3.1	Before installation	14
3.3.2	Linear bracket installation	14
3.3.3	How to connect Spring lever and Stem connection pin	15
3.3.4	Install with Positioner	15
3.4	Rotary type	16
3.4.1	NAMUR type	16
3.4.2	Lever type	16
<b>4</b>	<b>Electrical connection</b>	17
4.1	Standard type	17
4.2	Limit switch type	17
<b>5</b>	<b>How to setup</b>	18
5.1	2 Point setting	18
5.2	5 Point setting	18
5.3	RA/DA setting	18
<b>6</b>	<b>How to correct Potentiometer gear position</b>	19

## 1 Introduction

### 1.1 General information for the user

This instruction includes installation, operation, maintenance, and parts information for TS500 series.

Keep these instructions in a location which is easily accessible to every user and make these instructions available to every new owner of the device.

- Installation, commissioning and maintenance of the product can only be performed by trained specialist personnel who have been authorized by the plant operator to do so.
- To avoid possible injury to the personnel or damage to valve parts, WARNING, CAUTION and NOTICE must be strictly followed.
- Before installing or commissioning, be sure to read and thoroughly understand the product manual and operate the product properly.
- Operators must strictly observe the applicable national regulations with regards to installation, function tests, repairs, and maintenance of electrical products.
- For additional information or if specific problems occur that are not explained in these instructions, contact the manufacturer.

### 1.2 Limited warranty and disclaimer

- This product has been fully inspected and shipped through a thorough quality inspection procedure. The manufacturer warranty period of the product is 18 months after the product is shipped from Tissin in Korea.
- For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- Using the device in a manner that does not fall within the scope of its intended use, disregarding this manual, using under unqualified personnel, or making unauthorized alterations releases the manufacturer from liability for any resulting damage. This renders the manufacturer's warranty null and void.

### 1.3 Requirements for safety

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. These safety instructions are intended to prevent hazardous situations and/or equipment damage. For the safety, it is important to follow the instructions in the manual.

---

 **WARNING**

Failure to observe the warning may result in serious injuries or death.

 **CAUTION**

Failure to observe this warning may result in damage to the device or personal injury.

 **NOTICE**

Failure to observe the warning may result in damage to the device or may degrade performance.

---

#### Safety notes

 **CAUTION**

---

- Only trained and authorized person should operate the machinery and the equipment.
- If it is out of the specification range, it may cause a malfunction, so please use it in compliance with the product specification.
- Never handle mechanical equipment or disassemble the device until safety is confirmed.
- Before reaching into the device or the equipment, please switch off the power supply and secure to prevent reactivation.
- Observe applicable accident prevention and the safety regulations for electrical equipment.

---

## 2 Product Description


### 2.1 Function

Smart position transmitter is a device that proportionally changes the valve opening into a 4-20mA DC current signal and transmits this information to DCS room or controller.

### 2.2 Features

- Easily check the feedback signal by built-in LCD
- Easy setting by 2 buttons
- High resolution and accuracy
- Improved accuracy of feedback signal by 5-point setting
- Limit switch option

### 2.3 Label



Item	Description
MODEL.	Model number
LOT No.	Serial number
AMBIENT TEMP.	Operating temperature
OUTPUT	Output current signal range
INGRESS PROTECTION	IP Ratings of Enclosure


## 2.4 Product code

<b>Model</b>	<b>TS500</b>			
<b>Acting type</b>	Linear	L		
	Rotary	R		
<b>Conduit entry</b>	NPT1/2	1		
	M20x1.5P	2		
	G1/2	3		
<b>Lever type</b>	Stroke 10~80mm (Linear type)	1		
	Stroke 70~150mm (Linear type)	2		
	NAMUR (Rotary type)	5		
<b>Option</b>	With LCD	1		
	Without LCD	2		
	With Limit switch and LCD	3		
	With Limit Switch and Dome cover	4		


## 2.5 Specification

Item	TS500
Connection type	2Wire
Supply voltage	9~28V DC
Output signal	4~20mA DC
Explosion proof	Non-explosion proof
Enclosure	IP67
Conduit entry	NPT1/2, M20, G1/2
Operating temp.	-40°C~70°C (standard)
Linearity	±1.0% F.S
Hysteresis	±0.2% F.S
Sensitivity	±0.2% F.S
Coating	Polyester powder coating
Material	Aluminum die casting
Weight	0.6kg


## 2.6 Exploded view



<TS500 with LCD>




<TS500 with LCD and Limit switch>




<TS500 with Limit switch and Dome>

## 2.7 Principle of operation


If the position of valve stem changed, this change makes the main gear of main shaft rotate by the connected lever, and it also make the resistance value of potentiometer change. The change in resistance value proportionally changes the current value in the circuit, and this information is transmitted to Calibrator or DCS.



## 2.8 Product Dimension



<TS500 with Standard cover>



<TS500 with Dome cover>

## 3 Installation

### 3.1 Before installation

---

 **WARNING**

---

- Before installation, shut off the air pressure and make sure that no air pressure remains inside the actuator.

---

### 3.2 Effective angle of operation


---

 **NOTICE**

---

- When install the product, the feedback lever must move within the effective angle range in figure below.
- If exceed the effective angle, the feedback signal can't be received normally.

---



### 3.3 Linear type installation

#### 3.3.1 Before installation

When make the mounting bracket and connecting the lever to the stem connection pin, be sure to observe the following two points.

If don't comply, it will affect the product performance such as linearity.


---

 **NOTICE**

---


- ① When the valve stroke is 50%, the feedback lever should be horizontal.
- ② When the valve stroke is 50%, the stem connection pin must be located at the numeric position marked on the feedback lever that is corresponding to the valve stroke.

---



#### 3.3.2 Linear bracket installation


Check the above two notices and refer to product dimensions and figure below to make/install the appropriate bracket to actuator.



### 3.3.3 How to connect Spring lever and Stem connection pin


When connecting the stem connecting pin, make sure to install the engraved position and spring lever accurately.

Below figure is a connection example for 40 mm valve stroke.



### 3.3.4 Install with Positioner


When mount it together with Positioner on the valve, please install them as below figure and connect the lever with same Stem connection pin.



### 3.4 Rotary type installation

#### 3.4.1 NAMUR type

Please mount bracket to the product using bolts. And mount the product's feedback shaft on Actuator's stem and fix it using bolts.



#### 3.4.2 Lever type

Refer to the figure below, please mount an appropriate bracket and Connection Lever on the product.


---

 **NOTICE**

---

- The length between Actuator's stem and Connection Lever must be the same as the length between Position transmitter's shaft and Connection Lever.
- If both lengths are not the same, the rotation angle of Actuator may not be transmitted accurately to Position transmitter, and it may affect the accuracy.

---




## 4 Electrical connection


### ⚠ NOTICE

- Please supply 9~28V DC to Output terminals
- To protect the product, ground it to the ground terminal inside and outside the product.

### 4.1 Standard type



### 4.2 Limit switch type




## 5 How to setup

### ⚠ NOTICE

In general, please set 2-Point setting corresponding to the valve position 0% and 100%.  
If you want a more precise feedback signal, please set 5-Point setting.

### 5.1 2-Point setting


- ① Supply 4mA to make the valve stroke 0%
- ② Press ZERO button for 2 seconds. Then the lamps are turned on and off sequentially.  
(※ If you want DA setting: Press END button for 2 seconds)
- ③ Supply 20mA to make the valve stroke 100%
- ④ Press END button for 2 seconds. Then the lamps are turned on and off sequentially.  
(※ If you want DA setting: Press ZERO button for 2 seconds)



### 5.2 5-Point setting

<Standard PCB>

- ① Supply 4mA to make the valve stroke 0% and press ZERO and END buttons at the same time for 2 seconds. Then No.4 lamp blinks.  
※ If you want DA setting output:
  - (1) Input 20mA to make the valve stroke 100% and press ZERO and END buttons at the same time for 2 seconds.
  - (2) Please proceed ②~⑤ in order of 20mA, 16mA, 12mA, 8mA, 4mA.
- ② Press ZERO button. Then the data is saved, and then it moves to No.8 lamp automatically and blinks.
- ③ Supply 8mA to make the valve stroke 25% and press ZERO button. The data is saved and it moves to No.12 lamp automatically and blinks.
- ④ In the same way, please set them in order of output 12mA, 16mA and 20mA according to each position of the valve 50%, 75% and 100%.
- ⑤ The lamps are turned off when the setting is complete.



<Limit switch type PCB>

### 5.3 RA/DA setting

- RA setting: Input 4mA, output 4mA / Input 20mA, output 20mA
- DA setting: Input 4mA, output 20mA / Input 20mA, output 4mA

※ Factory setting: RA setting

## 6 How to correct Potentiometer gear position

During transportation or installation, Potentiometer gear could be separated from Main gear due to strong shock or vibration, and the set position value could be changed. In this case, please correct the position of Potentiometer gear in the following way.

---

 **WARNING**


---

- When open the terminal cover, be sure to shut off all power sources first.
- Before installation, shut off the air pressure and make sure that no air pressure remains inside the actuator.

---

### How to correct

- ① Open the cover, loosen PCB fixing bolts, and unplug the two connection cables connected to PCB.
- ② Do not unplug the cable too hard.
- ③ There are three cables from Potentiometer (Black, Red, White). Please measure the resistance between Red cable and Black cable (or White cable) using 0.2mm metal pins.
- ④ Move the feedback lever to 50% position, and pushing Potentiometer gear and rotate the gear until the resistance is  $5k\Omega$ .
- ⑤ After correct the position, please release Potentiometer gear to meet Main gear.





## **Tissin Co.,Ltd.**

201-1105, No 397, Seokcheon-ro,  
Bucheon-si, Gyeonggi-do, Korea 14449  
Tel : +82-32-624-4573,  
Fax : +82-32-624-4574  
[www.tissin.co.kr](http://www.tissin.co.kr)

